# **M9384B VXG** Microwave Signal Generator

## Introduction

This configuration guide contains information to help you configure your M9384B VXG microwave signal generator to meet your requirements. Ordering optional capabilities at the time of purchase provides the lowest overall cost.





## Hardware

## Select options for channel 1

Option	Description	Additional information
Step 1. Add firs	t channel (required)	
M9384B-001	Add channel 1	
Step 2. Select f	requency range on channel 1 (required)	
M9384B-F14	Frequency range, 1 MHz to 14 GHz (APC 3.5 mm male)	
M9384B-F20	Frequency range, 1 MHz to 20 GHz (APC 3.5 mm male)	
M9384B-F32	Frequency range, 1 MHz to 31.8 GHz (2.4 mm male)	
M9384B-F44	Frequency range, 1 MHz to 44 GHz (2.4 mm male)	
Step 3. Select F	RF bandwidth on channel 1 (required)	
M9384B-D05	RF bandwidth, 500 MHz with 256 MSa memory	Requires F14 or F20
M9384B-D06	RF bandwidth, 500 MHz with 256 MSa memory	Requires F32 or F44
M9384B-D10	RF bandwidth, 1 GHz with 256 MSa memory	Requires F14 or F20
M9384B-D11	RF bandwidth, 1 GHz with 256 MSa memory	Requires F32 or F44
M9384B-D20	RF bandwidth, 2 GHz with 256 MSa memory	Requires F14 or F20
M9384B-D21	RF bandwidth, 2 GHz with 256 MSa memory	Requires F32 or F44
M9384B-D2E	RF bandwidth, 2 GHz with 256 MSa memory, limited	Requires F32 or F44
Step 4. Select r	eference (required)	
M9384B-500	High performance reference	
M9384B-600	Enhanced high performance reference	
Step 5. Select p	hase noise performance on channel 1 (required)	
M9384B-ST5	Low phase noise	Requires 500
M9384B-ST6	Enhanced low phase noise	Requires 600
Step 6. Add hig	h output power on channel 1 (optional)	
M9384B-1EB	High output power from 20 GHz to 44 GHz	Requires F32 or F44
M9384B-1EE	High output power from 20 GHz to 43.5 GHz, limited above 43.5 GHz	Requires F32 or F44
Step 7. Select v	rector system features on channel 1 (optional)	
M9384B-M05	Baseband generator memory upgrade to 512 MSa	
M9384B-M10	Baseband generator memory upgrade to 1024 MSa	
M9384B-EXT	Wideband differential external IQ inputs	
M9384B-DIQ	Differential IQ outputs	
M9384B-403	Calibrated AWGN	
Step 8. Select a	nalog modulation on channel 1 (optional)	
M9384B-PMR	Pulse modulation	
M9384B-PME	Limited pulse modulation	
M9384B-320	Pulse train generator (SCPI only)	Requires PMR or PME
Step 9. Select g	eneral performance features on channel 1 (optional)	
M9384B-PCH	Phase coherency for N channels	
M9384B-1EH	Improved harmonics below 2 GHz	



## Select options for channel 2

Option	Description	Notes
Step 1. Add sec	ond channel (optional)	
M9384B-002	Add channel 2	The reference and phase noise options selected on channel 1 will be automatically selected on channel 2.
Step 2. Select f	requency range on channel 2 (required)	
M9384B-F14	Frequency range, 1 MHz to 14 GHz (APC 3.5 mm male)	Requires F14 or F20 on channel 1
M9384B-F20	Frequency range, 1 MHz to 20 GHz (APC 3.5 mm male)	Requires F20 on channel 1
M9384B-F32	Frequency range, 1 MHz to 31.8 GHz (2.4 mm male)	Requires F32 or F44 on channel 1
M9384B-F44	Frequency range, 1 MHz to 44 GHz (2.4 mm male)	Requires F44 on channel 1
Step 3. Select F	F bandwidth on channel 2 (required)	
M9384B-D05	RF bandwidth, 500 MHz with 256 MSa memory	Requires F14 or F20
M9384B-D06	RF bandwidth, 500 MHz with 256 MSa memory	Requires F32 or F44
M9384B-D10	RF bandwidth, 1 GHz with 256 MSa memory	Requires F14 or F20
M9384B-D11	RF bandwidth, 1 GHz with 256 MSa memory	Requires F32 or F44
M9384B-D20	RF bandwidth, 2 GHz with 256 MSa memory	Requires F14 or F20
M9384B-D21	RF bandwidth, 2 GHz with 256 MSa memory	Requires F32 or F44
Step 4. Select h	igh output power on channel 2 (optional)	
M9384B-1EB	High output power from 20 GHz to 44 GHz	Requires F32 or F44
M9384B-1EE	High output power from 20 GHz to 43.5 GHz, limited above 43.5 GHz	Requires F32 or F44
Step 5. Select v	ector system features on channel 2 (optional)	
M9384B-M05	Baseband generator memory upgrade to 512 MSa	
M9384B-M10	Baseband generator memory upgrade to 1024 MSa	
M9384B-403	Calibrated AWGN	
Step 6. Select a	nalog modulation on channel 2 (optional)	
M9384B-PMR	Pulse modulation	
M9384B-PME	Limited pulse modulation	
M9384B-320	Pulse train generator (SCPI only)	Requires PMR or PME
Step 7. Select g	eneral performance features on channel 2 (optional)	
M9384B-1EH	Improved harmonics below 2 GHz	

## **Select accessories**

#### Select accessories (optional)

Y1164A	Rack mount kit for M9384B
Y1165A <sup>1</sup>	Additional removable solid-state drive
Y1260A	Micro GPIB Cable
11900B <sup>2</sup>	Adapter, 2.4 mm (f) to 2.4 mm (f), DC to 50 GHz
11904B <sup>2</sup>	Adapter, 2.4 mm (f) to 2.9 mm (f), DC to 40 GHz
83059B <sup>3</sup>	Coaxial Adapter, 3.5 mm (f) to 3.5 mm (f), DC to 26.5 GHz

## Software

### **Included software**

#### Step 1. Start with the M9384B VXG base configuration

- The VXG base configuration includes the following software:
- PathWave General Purpose Signal Generation
- · Keysight IO Libraries Suite including Connection Expert
- · Sample waveforms and programming examples

### PathWave software tools

#### Step 2: Add PathWave Software Tools<sup>4,5</sup> (optional)

N7631APPC	PathWave Signal Generation for 5G NR
N7621APPC	PathWave Signal Generation for basic multitone
N7642APPC	PathWave Signal Generation for IQ based AM, FM, phase modulation
N7653APPC	PathWave automatic channel response correction and S-parameter de-embedding

<sup>&</sup>lt;sup>5</sup> PathWave software tools can be used to create, download, and playback waveforms through the VXG touch-optimized graphical user interface.



<sup>&</sup>lt;sup>1</sup> If PathWave or Signal Studio software will be added to a purchase which also includes an additional removable SSD, it is

recommended to select floating, transportable, or USB portable license types. Node-locked licenses enable a single SSD. <sup>2</sup> When options F32 or F44 are ordered, each channel of the M9384B VXG includes one 11900B adapter and one 11904B adapter to help interface with the 2.4 mm (m) RF output. Additional adapters of interest can be found here.

<sup>&</sup>lt;sup>3</sup> When options F14 or F20 are ordered, each channel of the M9384B VXG includes one 83059B adapter and two APC-3.5mm (f) to APC-3.5mm (m) adapters.

<sup>&</sup>lt;sup>4</sup> For more information, see PathWave Signal Creation - Brochure, literature number 5989-6448EN.

## Signal Studio and MATLAB

#### Step 3: Add Signal Studio and MATLAB Software (optional)

Cellular Communications		
Signal Studio for W-CDMA/HSPA+, waveform playback		
Signal Studio for cdma2000/1xEV-DO, waveform playback		
Signal Studio for GSM/EDGE/Evo, waveform playback		
Signal Studio for TD-SCDMA/HSPA, waveform playback		
Signal Studio for LTE/LTE-Advanced/LTE-A Pro FDD, waveform playback		
Signal Studio for LTE/LTE-Advanced TDD, waveform playback		
Signal Studio Pro for Pre-5G, waveform playback		
Signal Studio Pro for 5G NR, waveform playback		
vity		
Signal Studio for Bluetooth, waveform playback		
Signal Studio for IoT, waveform playback		
Signal Studio for mobile WiMAX, waveform playback		
Signal Studio for WLAN 802.11, waveform playback		
dcasting, Public Safety		
Signal Studio for broadcast radio, waveform playback		
Signal Studio for digital video, waveform playback		
Signal Studio for LMR, waveform playback		
ning, Tracking & Navigation		
Signal Studio for Global Navigation Satellite System (GNSS), waveform playback <sup>7</sup>		
owave		
Signal Studio Pro for Custom Modulation, waveform playback		
Signal Studio for power amplifier test		
MATLAB software		



<sup>&</sup>lt;sup>6</sup> Signal Studio licenses can be used to playback exported waveforms offline. <sup>7</sup> Real-time signal generation is not supported.

## **Post-purchase Upgrades**

Your product can be easily upgraded after the initial purchase. Some M9384B VXG microwave signal generator options are controlled by a licensing key and can be quickly installed by the user. To upgrade these options:

- 1. Contact your Keysight representative to place an order for an option upgrade.
- 2. You will receive your entitlement certificate via email.
- 3. Redeem the certificate online by following the instructions provided to receive a license key file.
- Install the license key file using the Keysight License Manager and SFP. Detailed installation instructions can be found here: https://www.keysight.com/us/en/assets/9922-03842/installationguides/M9383B-and-M9384B-Options-Upgrade-Installation-Guide.pdf
- 5. Begin using the new capability.

Some M9384B VXG microwave signal generator options require additional hardware. Contact your Keysight representative for assistance with hardware upgrades.

Upgrades are applied per channel. To upgrade both channels of a two-channel M9384B VXG, quantity 2 of the desired upgrade should be ordered.

Upgrade number	Description	Requirements	Additional information
Bandwidth			
M9384BU-D10	Upgrade bandwidth from 500 MHz to 1 GHz for frequency options F14 and F20	D05	Customer installable, license key
M9384BU-D11	Upgrade bandwidth from 500 MHz to 1 GHz for frequency options F32 and F44	D06	Customer installable, license key
M9384BU-D20	Upgrade bandwidth from 1 GHz to 2 GHz for frequency options F14 and F20	D10	Customer installable, license key
M9384BU-D21	Upgrade bandwidth from 1 GHz to 2 GHz for frequency options F32 and F44	D11	Customer installable, license key
M9384BU-D2E	Upgrade bandwidth from 500 MHz to 2 GHz for frequency options F32 and F44, limited	D06	Customer installable, license key
Memory Upgrade	S		
M9384BU-M05	Upgrade baseband generator memory from 256 MSa to 512 MSa	None	Customer installable, license key
M9384BU-M10	Upgrade baseband generator memory from 256 MSa to 1024 MSa	None	Customer installable, license key
M9384BU-M11	Upgrade baseband generator memory from 512 MSa to 1024 MSa	M05	Customer installable, license key



Jpgrade number	Description	Requirements	Additional information
Vector System Fe	atures		
M9384BU-403	Add calibrated AWGN	None	Customer installable, license key
M9384BU-DIQ	Add differential IQ outputs	None	Only available on channel 1 Customer installable, license key
M9384BU-EXT	Add wideband differential external IQ inputs	None	Only available on channel 1 Customer installable, license key
Pulse Modulation			
M9384BU-PME	Add limited pulse modulation	None	Customer installable, license key
M9384BU-PMR	Add pulse modulation	None	Customer installable, license key
General Performa	nce Features		
M9384BU-1EH	Add improved harmonics below 2 GHz	None	Customer installable, license key
M9384BU-PCH	Add phase coherency for N channels	002	Customer installable, license key
Output Power			
M9384BU-1EE	Add high output power from 20 GHz to 43.5 GHz, limited above 43.5 GHz	F32 or F44	Customer installable, license key
M9384BU-1EB	Add high output power from 20 GHz to 44 GHz	F32 or F44	Customer installable, license key
Reference			
M9384BU-600	Upgrade to enhanced high performance reference	500, ST6	Customer installable, license key
Phase Noise			
M9384BU-ST6	Upgrade to enhanced low phase noise	ST5, 600	Customer installable, license key
Frequency			
M9384BU-F20	Upgrade frequency from 14 GHz to 20 GHz	F14	Customer installable, license key
M9384BF-U01	Upgrade one channel from F20/D05 to F32/D06 with ST5/500	F20, D05, ST5, 500	Factory installable only, hardware
M9384BF-U02	Upgrade one channel from F20/D10 to F32/D11 with ST5/500	F20, D10, ST5, 500	Factory installable only, hardware
M9384BF-U03	Upgrade one channel from F20/D20 to F32/D21 with ST5/500	F20, D20, ST5, 500	Factory installable only, hardware
M9384BU-F44	Upgrade frequency from 32 GHz to 44 GHz	F32	Customer installable, license key

Upgrade number	Description	Requirements	Additional information
Add Second Chan	nel		
M9384BF-102	Add second channel with frequency range 1 MHz to 14 GHz with ST5/500	F14 or F20, ST5, and 500 on channel 1	Factory installable only, hardware
M9384BF-112	Add second channel with frequency range 1 MHz to 14 GHz with ST6/600	F14 or F20, ST6, and 600 on channel 1	Factory installable only, hardware
M9384BF-202	Add second channel with frequency range 1 MHz to 31.8 GHz with ST5/500	F32 or F44, ST5, and 500 on channel 1	Factory installable only, hardware
M9384BF-212	Add second channel with frequency range 1 MHz to 31.8 GHz with ST6/600	F32 or F44, ST6, and 600 on channel 1	Factory installable only, hardware

## Services

Select KeysightCare, warranty, and start-up assistance (optional)

The base configuration includes the following services:

- One day of start-up assistance
- KeysightCare Assured first year support

KeysightCare Upgrades		
R-55A-001-2	KeysightCare – Extend to 2 years KeysightCare Assured	
R-55A-001-3	KeysightCare – Extend to 3 years KeysightCare Assured	
R-55A-001-5	KeysightCare – Extend to 5 years KeysightCare Assured	
R-55B-001-1	Upgrade to 1-year KeysightCare Enhanced	
R-55B-001-2	Upgrade to 2 years KeysightCare Enhanced	
R-55B-001-3	Upgrade to 3 years KeysightCare Enhanced	
R-55B-001-5	Upgrade to 5 years KeysightCare Enhanced	
R-55C-001-1	Upgrade to 1-year KeysightCare Performance	
R-55C-001-2	Upgrade to 2 years KeysightCare Performance	
R-55C-001-3	Upgrade to 2 years KeysightCare Performance	
R-55C-001-5	Upgrade to 2 years KeysightCare Performance	

### KeysightCare

KeysightCare offers the industry's first cloud-based customer experience with dedicated, proactive support through a single point of contact for instruments, software, and solutions. Get faster response times, faster access to specialized experts and faster time to resolution.



### **Global Warranty**

Keysight provides the peace of mind that today's high-tech industry requires. Your investment is protected by Keysight's global reach in more than 100 countries (either directly or through distributors). The warranty gives you convenient standard coverage for the country in which the product is used, eliminating the need to ship equipment back to the country of purchase. Keysight's warranty service provides:

- All parts and labor necessary to return your investment to full specified performance
- Recalibration for products supplied originally with a calibration certificate
- Return shipment

### **One Day Start-up Assistance**

To give you the most value from your investment, your Keysight purchase includes Startup Assistance, a service that includes consultation from an expert application engineer. He or she will help you configure the system and offer training on topics most beneficial to you, anything from theory and basic usage to new features and benefits or even more advanced training specific to your application. Startup Assistance provides a customized consultation, getting you to the results you need more quickly.

## **Related Literature**

For more detailed product and specification information, refer to the following literature and web pages:

- VXG M9384B and VXG-m M9383B Data Sheet: https://www.keysight.com/us/en/assets/3119-1054/data-sheets/5992-4260.pdf
- PathWave Signal Creation Brochure: https://www.keysight.com/us/en/assets/7018-01538/brochures/5989-6448.pdf

Keysight enables innovators to push the boundaries of engineering by quickly solving design, emulation, and test challenges to create the best product experiences. Start your innovation journey at www.keysight.com.



This information is subject to change without notice. © Keysight Technologies, 2018 – 2022, Published in USA, December 19, 2022, 5992-3671EN